




FHP - SERIES FLOATING - DECANTER PUMP

DIMENSIONS



FHP4-8

To prevent a possible damage to the cable that may be caused by a strain on it, install the pump after filling the tank with the minimum predetermined amount of water.

DIMENSIONS:USCS (Inch)

Model	HP	Nominal Dia.	Pump & Motor						Water Level		*Wt. (lbs.)
			A	A1	B	B1	D	H	W1	W2	
FHP4-8	1	2"	33 7/16	15 13/16	28 1/4	4 5/16	28 3/4	39 3/4	7 1/8	11 5/8	106

*Excluding Cable

DIMENSIONS:METRIC (mm)

Model	kW	Nominal Dia.	Pump & Motor						Water Level		*Wt. (kg)
			A	A1	B	B1	D	H	W1	W2	
FHP4-8	0.75	50	850	401	718	109	730	1009	180	295	48